

TABLE OF CONTENTS

1	PURPOSE	6
2	CANCELLATION/EFFECTIVE DATE	6
3	RELATED FAR/JAR SECTIONS AND ADVISORY MATERIAL.....	6
4	RELATED DOCUMENTS.....	7
5	DEFINITIONS AND ACRONYMS	8
5.1	DEFINITIONS	8
5.2	ACRONYMS	12
6	BACKGROUND.....	15
7	GENERAL	16
7.1	FLIGHT GUIDANCE SYSTEM FUNCTIONS	16
7.2	FGS COMPONENTS	16
7.3	COMPLIANCE WITH FAR/JAR 25.1329	17
8	FLIGHT GUIDANCE SYSTEM ENGAGEMENT, DISENGAGEMENT AND OVERRIDE..	20
8.1	AUTOPILOT ENGAGEMENT/DISENGAGEMENT AND INDICATIONS	20
8.1.1	Autopilot Engagement.....	20
8.1.2	Autopilot Disengagement.....	21
8.1.2.1	Autopilot Disengagement Alerts	21
8.1.2.2	Quick Disengagement Control	21
8.1.2.3	Alternative Means of Autopilot Disengagement	22
8.1.2.5	Flight Crew Pitch Trim Input	22
8.2	FLIGHT DIRECTOR ENGAGEMENT/DISENGAGEMENT AND INDICATIONS	22
8.2.1	Flight Director Engagement	23
8.2.1.1	Guidance Cue(s).....	23
8.2.1.2	Reactive Windshear Flight Director Engagement	23
8.2.2	Flight Director Disengagement	23
8.3	AUTOTHROTTLE ENGAGEMENT/DISENGAGEMENT AND INDICATIONS.....	24
8.3.1	Autothrust Engagement	24
8.3.2	Autothrust Disengagement	24
8.3.2.1	Autothrust Quick Disengagement Control	25
8.4	FLIGHT CREW OVERRIDE OF THE FGS	25
8.4.1	Autopilot.....	25
8.4.2	Autothrust.....	26
8.5	FGS ENGAGEMENT MODE COMPATIBILITY	26
9	CONTROLS, INDICATIONS AND ALERTS	27
9.1	FGS CONTROLS	27
9.2	FLIGHT GUIDANCE MODE SELECTION, ANNUNCIATION, AND INDICATION	27
9.3	FLIGHT GUIDANCE ALERTING (WARNING, CAUTION, ADVISORY, AND STATUS)	29
9.3.1	Alerting for Speed Protection	29
9.3.2	Loss of Autopilot Approach Mode	29
9.3.3	Awareness of Potential Significant Transient Condition ("Bark before Bite")	29
9.4	FGS CONSIDERATIONS FOR HEAD-UP DISPLAYS (HUD).....	30
9.4.1	Characteristics of HUD Guidance	30
9.4.2	HUD Flight Guidance System Display.....	31
9.4.3	Head-Up/Head-Down Display Compatibility	31
9.4.4	Alerting Issues.....	32

9.4.5 Upset/Unusual Attitude Recovery Guidance	33
10 PERFORMANCE OF FUNCTION.....	34
10.1 NORMAL PERFORMANCE.....	34
10.2 PERFORMANCE IN RARE NORMAL CONDITIONS	35
10.2.1 Icing Considerations.....	36
10.3 PERFORMANCE IN NON-NORMAL CONDITIONS	36
10.4 SPEED PROTECTION (25.1329(h))	36
10.4.1 Low Speed Protection	37
10.4.1.1 Low Speed Protection during Approach Operations.....	38
10.4.1.2 Windshear	38
10.4.2 High Speed Protection.....	39
11 CHARACTERISTICS OF SPECIFIC MODES.....	40
11.1 LATERAL MODES	40
11.1.1 Heading or Track Hold.....	40
11.1.2 Heading or Track Select.....	40
11.1.3 Lateral Navigation Mode (LNAV).....	40
11.2 VERTICAL MODES.....	41
11.2.1 Vertical Speed Mode	41
11.2.2 Flight Path Angle Mode	41
11.2.3 Airspeed (IAS)/Mach Hold [Speed on elevator]	41
11.2.4 Airspeed (IAS)/Mach Select Mode [Speed on elevator]	42
11.2.5 Flight Level Change (FLCH) [Speed on elevator]	42
11.2.6 Altitude Capture Mode.....	42
11.2.7 Altitude Hold Mode.....	43
11.2.8 Vertical Navigation Mode (VNAV).....	43
11.3 MULTI-AXIS MODES.....	44
11.3.1 Takeoff Mode	44
11.3.2 Go-Around Mode	45
11.3.3 Approach Mode.....	45
11.4 AUTOTHROUST MODES	46
11.4.1 Thrust Mode	46
11.4.2 Speed Mode.....	46
11.4.3 Retard Mode	46
11.5 SPECIAL CONSIDERATIONS FOR VNAV APPROACH OPERATIONS RELATED TO SELECTING A TARGET ALTITUDE.....	46
11.6 CONTROL WHEEL STEERING (CONTROL STEERING THROUGH THE AUTOPILOT)	46
11.7 SPECIAL CONSIDERATIONS FOR THE INTEGRATION OF FLY-BY-WIRE FLIGHT CONTROL SYSTEMS AND FGS.....	48
12 FLIGHT GUIDANCE SYSTEM INTEGRATION.....	49
12.1 SYSTEM INTEGRATION ISSUES.....	49
12.2 FUNCTIONAL INTERFACES.....	49
13 SAFETY ASSESSMENT	51
13.1 FGS FAILURE CONDITIONS	51
13.2 TYPE AND SEVERITY OF FAILURE CONDITIONS	52
13.3 FAILURE CONDITION – MITIGATION	52
13.4 VALIDATION OF FAILURE CONDITIONS	53
13.5 SPECIFIC CONSIDERATIONS	53
13.5.1 FGS Function during Ground Operations.....	53
13.5.2 FGS Operations in close proximity to the ground	54
13.5.2.1 Takeoff.....	54
13.5.2.1.1 Vertical Axis Assessment.....	54
13.5.2.1.2 Lateral Axis Assessment.....	54

13.5.2.2	Approach.....	54
13.5.2.2.1	Vertical Axis Assessment.....	55
13.5.2.2.2	Lateral Axis Assessment.....	55
13.5.3	Cruise Operations	56
13.5.4	Asymmetric Thrust during Autothrust Operation.....	56
13.6	FAILURE TO DISENGAGE THE FGS	56
14	COMPLIANCE DEMONSTRATION USING FLIGHT TEST AND SIMULATION	57
14.1	PERFORMANCE DEMONSTRATION (FAULT FREE) – FAR/JAR 25.1301	58
14.1.1	Normal Performance	59
14.1.2	Rare Normal Performance	59
14.1.2.1	Icing Considerations	59
14.1.2.2	Windshear	60
14.1.2.3	Indication and Response to an Out of Trim Condition.....	60
14.1.3	Specific Performance Conditions	60
14.1.3.1	Low Speed Protection	60
14.1.3.2	High-speed Protection.....	60
14.1.3.3	Go-around.....	61
14.1.3.4	Steep Approach [Special Authorization].....	61
14.1.4	Flight Director / HUD Considerations.....	62
14.1.4.1	Specific Demonstrations for Head-Up Display	62
14.1.4.2	Simulator Demonstration for Head-Up Display (HUD).....	63
14.1.5	Flight Crew Override of the Flight Guidance System	64
14.1.5.1	Autopilot Override	64
14.1.5.2	Autothrust Override	64
14.1.5.3	Pitch Trim System Evaluation during an Autopilot Override	65
14.2	FAILURE CONDITIONS REQUIRING VALIDATION – FAR/JAR 25.1309.....	65
14.2.1	Validation Elements	65
14.2.1.1	Failure Condition	65
14.2.1.2	Pilot Recognition	66
14.2.1.3	Pilot Reaction Time	66
14.2.1.4	Pilot Recovery.....	67
14.2.2	Takeoff	67
14.2.3	Climb, Cruise, Descent and Holding	67
14.2.4	Maneuvering.....	67
14.2.5	Approach	68
14.2.5.1	Approach with Vertical Path Reference	68
14.2.5.2	Approach Without Vertical Path Reference	69
14.2.5.3	Steep Approach	69
14.2.6	Specific Conditions	69
14.3	CRITERIA SUPPORTING THE OPERATIONAL USE OF AN AUTOPILOT	69
14.3.1	Autopilot Operations in close proximity the ground	69
14.3.1.1	Autopilot Engagement Altitude or Height after Takeoff – Failure Effects	70
14.3.1.2	Autopilot Engagement during Approach	70
14.3.1.2.1	Approach with Vertical Path Reference – Failure Effects	71
14.3.1.2.2	Approach without Vertical Path Reference	71
14.3.1.3	Circling Approach.....	72
14.3.2	Climb, Cruise, Descent, and Holding	72
14.3.3	Maneuvering.....	72
14.4	AUTOMATIC DISENGAGEMENT OF THE AUTOPILOT.....	72
14.5	ASSESSMENT OF HUMAN FACTORS CONSIDERATIONS	72
15	AIRPLANE FLIGHT MANUAL (AFM).....	74
15.1	INFORMATION SUPPORTING OPERATIONAL USE OF THE AUTOPILOT.....	74
15.2	LIMITATIONS	74
15.3	NON-NORMAL/EMERGENCY PROCEDURES	74
15.4	NORMAL PROCEDURES	75
15.4.1	Aircraft with Published Flight Crew Operation Manuals	75

15.4.2 Aircraft without Published FCOM's	75
<u>APPENDIX A - SAFETY ASSESSMENT</u>	76
A1 GENERAL	76
A2 IDENTIFICATION OF FAILURE CONDITIONS	76
A3 CONSIDERATIONS WHEN ASSESSING THE SEVERITY OF FAILURE CONDITION EFFECTS.....	76
A4 FAILURE CONDITION CLASSIFICATION	77
A4.1 Catastrophic Failure Conditions	77
A4.2 Hazardous Failure Conditions	78
A4.3 Major Failure Conditions	78
<u>APPENDIX FT - FLIGHT TEST PROCEDURES</u>	79
FT.1 GENERAL	79
FT.2 PROTECTION FEATURES	79
FT2.1 Low Speed Protection	79
FT2.2 High-speed Protection	81
FT.3 ENVIRONMENTAL CONDITIONS	82
FT.3.1 Icing.....	82
FT.4 FAILURE CONDITIONS	83
FT.4.1 Test Methods	83
FT.4.2 Fault Recognition and Pilot Action	83
FT.4.2.1 Takeoff.....	83
FT.4.2.2 Climb, Cruise, Descent and Holding and Maneuvering.....	84
FT.4.2.3 Approach.....	84
FT.4.2.3.1 Fault Demonstration Process	84
FT.4.2.3.2 Assessment – Approach with Vertical Path Reference	84
FT.4.2.3.3 Assessment – Approach without Vertical Path Reference	84
FT.4.2.3 Autopilot Override.....	87